

Open MR Indicator

Article No : 1006559



Open MR Indicator is used with Leksell® Coordinate Frame G for accurate coordinate referencing in MR scanning. The two side plates enable lower frame fixations & improved patient comfort.

The kit contains; 1 Plate Holder, 1 Right Side Plate, 1 Left Side Plate, 8 Side Plate Screws, 6 Sealing Screws, 2 Attachment Clips for Indicator, 1 Side Plate Screwdriver, 1 Sealing Screwdriver, 1 Copper Sulfate Solution 0.25 L, 1 Filling Needle.

It is easy to use thanks to the clear-cut design with only lateral plates and the handle-like connection between the indicator box and Leksell® Coordinate Frame G. The open design allows fast and obstacle free mounting as well as improved patient comfort.

The solid, gap-free attachment to the frame provides very high and stable accuracy. Since Open MR Indicator doesn't have a top plate there is no limit as to how low the frame may be mounted. The need for refilling the fiducial plates with fluid is minimized with the tight sealing screws.