

MR Indicator Screw & O-Ring Spare Part Kit

Article No : 812919



Spare part kit for MR Indicator (Article No A0820-07) consisting of Sealing Screws - 50 pcs, O-Rings - 50 pcs and MR Indicator Screwdriver - 1 pcs.