

Stop with 3,5 mm hole

Article No : 60080-35

The guide insert and the stop insert are used to guide the instrument into position on the stereotactic arc. The stop insert sets the limit of instrument insertion to the appropriate target depth. Stop with 3,5 mm hole